

HYDROKON®

WATER TRANSFER FILM



HYDROKON PVA FILM USER GUIDE

IMAGE PREPARATION

1. Print on the coated side of the film. Coated side has a matte appearance.
2. After printing, let dry for approximately 30 minutes.
3. If using latex ink, printed film is immediately ready for dipping.
4. If using pigment ink, apply a light coat of lacquer, or fixative, to printed side of film only. See suggestions below.
 - a. Be sure to use within 2 weeks of lacquer application.
 - b. Recommended Lacquer: [Rust-Oleum Clear Lacquer Spray](#) or clear basecoat/intercoat from your hydrographic paint company.

PREPARATION OF ITEMS TO DIP

1. Degrease Object
2. Perform Flame Treatment
 - a. If acetone doesn't affect the surface, most likely needs flame treatment.
 - b. ABS plastic is the only type of plastic that should not need flame treatment.
3. Scuff/Bead Blast
 - a. Use a heavy-duty scouring pad (e.g. Scotch-Brite), to roughen the surface.
4. Base Coat Application
 - a. For an ideal base coat, primer or an adhesion promoter may be necessary depending on object and/or paint.

DIPPING INSTRUCTIONS

1. Cut printed film to size needed and then remove the clear backer.
2. The film is then placed on the water, printed side up.
3. Recommended water temperature is 90° F (32° C).
4. Film should dwell on the water for 60-75 seconds.
5. Spray with activator. We recommend a 'cool' activator. Examples:
 - a. [Superbrew from K2](#)
 - b. [Ink Drink from OHW](#)
 - c. [Hydro Solutions Activator](#)
6. After hydro dipping object, the PVA film is removed by rinsing with water. Warm water speeds up PVA removal, but temperature should not exceed 120° F to be sure the image is not removed during rinsing.
7. After object is rinsed, the surface should no longer feel slimy. Hydrokon PVA, however, has a special fluorescent indicator quality that guarantees PVA removal. Using a UV blacklight, the PVA will glow, making it easier to determine when all the PVA has been removed. If a bluish/white glow is still present on the surface, rinse the object for a longer period of time.
8. After PVA removal, allow object to dry completely.
9. Apply your favorite clear coat for surface protection.

STORAGE

- Hydrokon film should be stored between 68°-75° F.
- It is suggested for relative humidity levels to be between 45-60%.

[Watch The Dipping Process On Our YouTube Channel!](#)



Toll Free: 1-800-328-4261
(Outside North America Call
+1-218-628-2217)

IKONICS
Corporation

www.ikonics.com



ISO 9001 Certified | NASDAQ Listed: IKNX

210203